

IMPORTANT SAFETY WARNING

LEISURE & FLAVEL GAS COOKERS

It has recently come to our attention that particular Leisure and Flavel cookers with a separate oven and grill can, if they are not operated in accordance with the user instructions, pose a **serious risk to your health**.

CHECK THE LIST BELOW TO SEE IF YOU OWN ONE OF THE AFFECTED COOKERS.

| Brand | Product Model Number |
|---------------|----------------------|
| Leisure | CM10NRK |
| Leisure | CM10NRC |
| Leisure | AL6NDW |
| Leisure | CM101NRCP |
| Leisure | CM101NRKP |
| Flavel | DCGAP5LS |
| Flavel | AP5LDW |
| Flavel Milano | ML5NDS |

WHAT YOU NEED TO DO IF YOU OWN ONE OF THESE COOKERS

- 1. FOLLOW THE PRODUCT INSTRUCTION MANUAL. DO NOT OPERATE THE GRILL WITH THE GRILL DOOR CLOSED.**

When the grill burner is on, the grill door must **always** be in the open position. If the grill is operated with the grill door closed, the air supply to the grill burner is restricted which can cause extremely dangerous levels of carbon monoxide to be produced which can pose a very serious risk to health.

- 2. ARRANGE FOR A FREE SAFETY INSPECTION AND MODIFICATION.**


If you own or use any of the models shown above, please call us on:

FREEPHONE 0800 294 3129

Between the hours of 8am and 6pm Monday to Friday

We will then arrange to carry out a **free modification** to your product to remove any risk.

When calling please have your full model number and serial number to hand – these can be found on the rating plate at the bottom front edge of the appliance (see details below).



Beko plc, Beko House, Caxton Way, Watford WD18 8UF
www.beko.co.uk www.leisurecp.co.uk